

Användare manual Lätt Eldrivet arbetsbord 150 kg

Första användning

- Se till att alla kablar från motorerna och handkontrollen är ordentligt intryckta i rätt öppning i styrboxen.
- Försäkra dig om att det finns ström i uttaget.
- När punkterna ovan är uppfyllda håll "Ner" knappen intryckt i 10 sekunder så styrboxen kalibrerar sig och hittar sin utgångs position.



Felsökning

Om bordet slutat att fungera finns några enkla åtgärder som kan få bordet att fungera igen.

- Se till att det finns ström i uttaget.
- Se till att alla kablar är helt intryckta i styrboxen.
- Nollställ bordet genom att hålla in "Ner" knappen i minst 10 sekunder när bordet är i bottenläget.

Hjälper inte något av ovanstående vänligen kontakta leverantören.

User manual Electric adjustable worktable 150 kg

First use

- Make sure that all cables from engines and hand control unit are properly attached in the right spots in trafo unit.
- Ensure that there is power in outlet.
- When remarks above is satisfied press "Down" button and hold it down for at least 10 seconds to reset the table.

Troubleshooting

If the worktable stops working there are some simple measures that can make the table start working again.

- Ensure that there is power in outlet.
- Make sure that all cables are properly attached in trafo unit.
- Reset table by holding "Down" button down for 10 seconds when table have reached its lowest point.

If nothing above make the table works again please contact the supplier.